

Directions for Assembling the Standalone Teleprompter



1. Attach the teleprompter to your tripod or place it on a table.
2. Open the teleprompter and attach the metal support by inserting one end into the hole on the glass side. Then insert the other end into the platform side. You will notice that the holes do not naturally align. This is part of the design. Use a little force to bend the support so it goes into the hole. The fit should be tight and the structure of the open teleprompter should be rigid.
3. Place your projection device (iPad, Android tablet, iPhone, or Smartphone) onto the platform.
4. Place your camera into position behind the teleprompter and get it ready to videotape.
5. Secure the black cape to the teleprompter by lining-up the Velcro tabs on the cape with those on the sides of the teleprompter.
6. Prepare the projection device by launching the teleprompter software.

These directions do not have to be performed in this particular order, but with experience you will develop your own method.

Go to Interactmedia.net to learn more. If you have questions, contact Scott at 248-660-4984. Thank you for your purchase.